



**7455.1007**


Onderdelen informatie

Erzatsteil information

Spare part information

Information de pièces





21	Power Switch	2	38	Crumb -	2
20	Electric Box	2	37	Heating Element Support	2
17	Microswitch	2	36	Heating Element	6
16	Terminal	2	35	Support	4
15	Cable Lock	2	34	Clamp 2	8
14	Contacter	2	33	Thermostat	2
13	Security Thermostat	2	32	Clamp 1	2
12	Handle for Cover	2	31	Oil Indicator	2
11	Cover	2	30	Perhook Per Frying Basket	2
8	Oil letout Pipe	2	29	Turning Axis	8
7	Handle for Basket	2	27	Heating Indicator Light	2
6	Frying Basket	2	26	Power Indicator Light	2
5	Valve	1	25	Base of the Knob	2
3	Gasket	2	24	Knob	2
2	Body	1	23	PVC	2
1	Plastic Leg	4	22	Electric Box Cover	2
NO.	Name	QTY	NO.	Name	QTY

Model